

ME Decor Group OÜ
Registration Number: 16329771
Legal address: Harju maakond, Tallinn,
Pohja-Tallinna linnaosa, Kopli tn 27, Estonia 10412


TM ME Floor engineered Plank Flooring installation guide
(glue-down to a subfloor)

1st stage. Before the installation:

- Make sure all the construction works are finished and flooring installation is a final step to do;
- Make sure relative air humidity and temperature are acceptable: 40-65% and 18-22 degrees.
- Deliver boxes with your hardwood flooring to the installation place and leave for a couple days. Do not open boxes in advance. The parquet needs to adapt to the temperature and humidity of the room. Please, follow this rule, especially in winter season or in case of international deliveries from different climatic zones, to avoid temperature and humidity “shocks” of hardwood floors.

2nd stage. Tools preparation:

- Marking cord (chalk line)
- Guide rail (metal) 3m; 2pcs
- Fixators for planks
- Mallet (elastic hammer for parquet)
- Tapping block
- Square or template (Control of 45°, 90° and 135° angles)
- Trowel (for applying glue)
- Miter saw
- Nail puller
- Hachsaw
- Vacuum Cleaner and Broom
- Repair kit for wood flooring
- Hardwood flooring cleaner
- Hammer
- Measuring tape
- Drill

A decorative horizontal band at the top of the page featuring a repeating pattern of stylized leaves in shades of grey and white against a dark background.

ME Decor Group OÜ
Registration Number: 16329771
Legal address: Harju maakond, Tallinn,
Pohja-Tallinna linnaosa, Kopli tn 27, Estonia 10412

- Finishing nails
- Moisture meter
- Underlay
- Spacers
- Adhesive
- Cloth
- Glue remover

3rd stage. Installation:

1. Before starting installation - draw a line parallel to the wall with the help of chalk or another marker.
2. Start installation leaving expansion gaps 10-15 mm along the long & short sides of the boards.
3. Start installation by gluing down from left to right. Make sure the plank's tongue is facing the wall out.
4. Continue installation row by row constantly making sure every row is installed properly.
5. Use cut planks to finish\start each row. It allows you saving long boards for the center of a room and making the pattern more natural.
6. After installation is finished, a space is recommended to cure for 24 hours before using (refer to your Adhesive manual for more details).
7. Install moldings if needed by fastening to the flooring not to the wall.
8. Do not forget to dedust the flooring after installation by a vacuum cleaner. Make sure, there is no glue on the surface of installed flooring. Use wet mop with micro-fibra to clean flooring. Using a hardwood flooring cleaner will ensure best cleaning result.

NOTE: ME Decor Group OU is not responsible over any costs incurred when planks with visible defects have been installed.