

# HARDWOOD FLOORING



## PRODUCT USE

#### 7. INSTALLATION



Glue down over concrete, plywood or wooden subfoor or nail down over wooden subfloor. Applicable above, on and below ground level.

Suitable for underfloor heating.

#### 8. STORAGE & USE

40-65% Air Humidity 40-65%

Temperature +18°C ... +22°C (64°F ... 72°F)

+22°0 72°F

18°C

**10. DESCRIPTIONS & IMAGERY** 

Flooring colors displayed in digital

settings of the monitor you are using.

platforms may vary according to the color

Floor

### 9. CARE & MAINTENANCE

Maintenance of hardwood floors with UV Silk assumes normal (daily if necessary) cleaning from dust and grit using a vacuum, followed by a thorough cleaning with floor cleaner. Floor surface areas that receive the most traffic and get worn down quicker, such as areas by the front door, hallways, kitchens etc. should be periodically renewed with oil.



ME Decor Group OÜ Kopli 27, 10412, Tallinn, Estonia VAT EE102590311 E-mail: info@me-decor.com www.me-floor.com Inst.: @me\_floor\_





